

AnyTone D578UV Mobile Radio Base Band Update Instruction


UNINSTALL AND REMOVE ALL OLD VERSIONS OF THE SCT_PORT.EXE PROGRAM BEFORE DOING THIS UPDATE– ONLY USE THE LATEST INSTALL PROGRAM

1. Press and Hold both the PUSH key (Channel Knob Push) and MENU key, and TURN ON THE RADIO and the screen will show “WARNING Boot Mode for Sct!!!”
2. Use the USB cable to connect radio and your PC
3. Run the **most current SetupSCT Port. msi** file provided in this update and install.




SetupSCT_PORT.msi



4. Run SCT_PORT Host Controller by Double Clicking on the Icon on your Desktop.






5. Follow the screen guides below to set the SCT_Port Host Controller to update the Base Band:





AnyTone D578UV Mobile Radio Base Band Update Instruction




AnyTone D578UV Mobile Radio Base Band Update Instruction



AnyTone D578UV Mobile Radio Base Band Update Instruction



AnyTone D578UV Mobile Radio Base Band Update Instruction



The update is now complete.

Unplug Radio Power Source to reboot radio.

Reapply Power and Turn Radio back on.