

.....Firmware Update Sequence.....

It seems that some people have a problem with the button pressing sequence when trying to put the D578UV into firmware update mode. The following procedure works for me 100% of the time.

- 1- Have the radio powered on
- 2- Place a finger on both the MENU and EXIT buttons, but do not press
- 3- Press and hold the POWER button
- 4- The INSTANT that the display goes dark, press and hold the MENU and EXIT buttons
- 5- Release the POWER button. The red light above the power button should blink slowly
- 6- Release the MENU and EXIT buttons. The red light should continue to blink and the radio is ready to accept the firmware update.